Savannah Square Columns



The **Savannah** square columns are completely maintenance free. Made of heavy gauge aluminum for even greater support.

The **Savannah** columns can

The *Savannah* columns can be painted in any desired color. Vinyl acrylic paint is recommended. Columns can also be pre-painted at the factory with a 30% up-charge. Easy to assemble and install. See instructions below.

7				
		A —		
	~	~	1	

SAVANNAH SQUARE COLUMNS					
Col. size	Standard Length	Approx. weight load*			
6"	8′ 9′ 10′ 12′	20,500			
8″	8′ 9′ 10′ 12′ 16′ 18′	26,500			

* Maximum Load – No Safety Factor Included Available in White only

SIZE	ACT. SIZE	CAP & BASE SIZE		
	A	В	C	D
6″	51/2"	73/8"	23/4"	2″
8″	71/2"	93/8"	23/4"	2″





ASSEMBLY and INSTALLATION



Measure the required length. Using a hack saw, cut the column slightly longer for a tight fit.



2 Fit the four sections together – tongue into groove. It is best to put two quarter sections together. Repeat with other two sections then join the two half sections together – tongue into groove – and tap with heel of the hand until sections snap and lock together.



3 Slide astragal ring over assembled column. Position at height desired (usually about 12 to 18 inches below the cap). Drill ½ inch hole through flat surface of astragal ring and into the column. Secure with 1 ¼ inch screws on at least two sides.



A Slide cap and base onto each end of the column. The column must extend through the cap and base for proper installation.



Secure columns in place (optional). Locate L-shaped brackets around column top and bottom. Drill holes and secure in place to upper and lower structure.



Secure caps in place. Drill two holes opposite each other, through caps and into column. Secure caps in place with screws.

